



J/B #: BBJ-WWC-R

JET \ Brella, INC.

Installation Instructions

NOSE WHEEL WELL UNDERCARRIAGE COVER



- ✓ Attach nose wheel well cover to the back of the nose wheel strut. (Figure 1) Attach clip (Figure 2)
- ✓ Pull the cover over the top of the nose wheel doors, from back to front. (Figure 3, 4)
- ✓ Tuck in the shoe laces and tie to door hinges. (Figure 5)
- ✓ Adjust cover for fitment over nose wheel doors. (Figure 6)
- ✓ Attach two front bungee loops over bolts inside the bay.
- ✓ Attach Velcro from front to back. (Figure 7)
- ✓ Secure nose wheel cover. Adjust top wetsuit material for proper fitment and sealing. (Figure 8)
- ✓ **CAUTION:** Watch out for hydraulic lines and hardware during install/removal & DO NOT damage. DO NOT attach wheel cover straps to hydraulic or electrical lines.
- ✓ Upon removal, inspect wheels.

JET \ BRELLA INC. 6849 HAYVENHURST AVENUE, VAN NUYS, CALIFORNIA U.S.A. 91406

TELEPHONE: 1-818-780-1769 FACSIMILE: 1-818-994-9456 WWW.JETBRELLA.COM

SALES EMAIL: SALES@JETBRELLA.COM TECH SUPPORT & SERVICE EMAIL: TECH@JETBRELLA.COM